


# DOOSAN Wheel Loader DL300-5




Filter		Interval(hr)
E/G Oil Filter	400504-00058	500
E/G Fuel Filter	400504-00158	1000
Element; Outer	400504-00180	2000
Element; Inner	400504-00181	2000
Suction Filter-Oil Tank	2474-9016A	2000
Return Filter-Oil Tank	400504-00035	1000
Filter-Fuel Tank	471-00105A	1000
Aircon Filter	400402-00007A	1000
T/M Filter	K1029612	1000
Element;Urea Tank	400504-00125	1000
Element-Brake Filter	K1055161	500
Element-Air Breather	K1029257	1000
Filter ASSY;Dosage	400406-00320	1000
Cartrage;Water Separator	400508-00063	1000



Tooth / Cutting edge	
Tooth	K1039299,
Adapter-Tooth	K1003612,
Cutting Edge(side)	K1005465,
Cutting Edge(Center)	K1005466,


Belt	
Aircon Belt	DS3202046




Seal kit	
Seal Kit-Steering	401107-01
Seal Kit-Lift	401107-01
Seal Kit-Bucket	401107-01




Bulb	
Bulb 24V 2W	515-00012A
Bulb-Halogen 24V 70W	K1010656
Bulb 24V 70W	2515-1016D4




Manual	
Parts Book	950106-01
Operation Manual	950106-01
	950106-01
Shop Manual	950106-01



Battery / fuse / relay		
Battery	300101-00327	200AH
Fuse 10A	2527-1016	
Fuse 15A	2527-1017	
Fuse 20A	2527-1018	





Fuse 20A

2527-1018

Fuse 30A

2527-1025

Fusible Link 27A

2527-1023A

Battery Relay

301202-00153